

Eddie Bauer[®] Dash Full-Zip Fleece Jacket. EB242

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest Width	19 1/2	21	22 1/2	24	25 1/2	27	29	31
Body Length	27 1/2	28 1/2	29 1/2	30 1/2	31 1/2	32 1/2	33	33 1/2
Sleeve Length	34 3/4	35 1/2	36 1/4	37	37 3/4	38 1/2	39 1/4	40

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.

BODY LENGTH

Measured from high point of shoulder from the front.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.